



Coding HT3/WB1 Remote Control 433MHz Hand Transmitters

Steel-Line OL4 Sectional Garage Door Opener



1. Additional transmitters can be coded as follows:

- ❖ Press the “RADIO SET” button for 1-2 seconds (*the courtesy light will flash once and stay on for 30 seconds*).
- ❖ During this 30 second time period press the push button on your remote until the courtesy light flashes twice (*the code has been accepted*)
- ❖ If the code is not accepted the courtesy light will stay on for 30 seconds, flash 4 times and then stay on for 2.5 minutes.

Repeat above procedure for all additional handsets.

Note: A maximum of 20 codes can be learned by the opener. If you attempt to code more than 20 transmitters the oldest code will be deleted.

2. Deleting transmitters:

Note: This procedure will clear all programmed remotes, wireless wall buttons and wireless keypads from the opener.

- ❖ Press and hold the “RADIO SET” button for 5 seconds (*the courtesy light will flash 7 times indicating all transmitters have been cleared from memory*).

Follow procedure 1. above to code new remote control hand transmitters.



Coding HT3/WB1 Remote Control 433MHz Hand Transmitters

Steel-Line OL6 Sectional Garage Door Opener



1. Additional transmitters can be coded as follows:

- ❖ Press the “RADIO SET” button for 1-2 seconds (*the OK LED will stay on and the unit will beep once*).
- ❖ Press the push button on your remote (*the OK LED will switch off and the unit will beep twice*).

Repeat above procedure for all additional handsets.

Note: A maximum of 20 codes can be learned by the opener. If you attempt to code more than 20 transmitters the oldest code will be deleted.

2. Deleting transmitters:

Note: This procedure will clear all programmed remotes, wireless wall buttons and wireless keypads from the opener.

- ❖ Press and hold the “RADIO SET” button for 8 seconds (*the OK light will flash 3 times indicating all transmitters have been cleared from memory*).

Follow procedure 1. above to code new remote control hand transmitters.

Coding HT3/WB1 Remote Control 433MHz Hand Transmitters

Steel-Line RD11 Roller Door Opener



1. Additional transmitters can be coded as follows:

- ❖ Press and release the “RADIO SET” button (*the OK LED will flash twice and you now have a 30 second window for coding*).
- ❖ During this 30 second time period press the push button on your remote (*the OK LED will flash once and the unit will beep twice indicating the code has been accepted*).

Repeat above procedure for all additional handsets.

Note: A maximum of 20 codes can be learned by the opener. If you attempt to code more than 20 transmitters the oldest code will be deleted.

2. Deleting transmitters:

Note: This procedure will clear all programmed remotes, wireless wall buttons and wireless keypads from the opener.

- ❖ Press and hold the “RADIO SET” button for 7 seconds (*the OK LED will flash twice and the unit will beep twice indicating all transmitters have been cleared from memory*).

Follow procedure 1. above to code new remote control hand transmitters.