






TO INSTALL

<p>1.</p>	<p>Remove soft plastic cover (if fitted).</p>	
<p>2.</p>	<p>Insert post base "key" into base plate on floor, taking note to orient post "key" to match shape in base plate.</p>	
<p>3.</p>	<p>Rotate post in base plate ¼ turn so that top arm faces wall bracket. Secure post temporarily (using Step #5) to a strut using the chain from one of chain brackets (this prevents post falling over while doing Step 4).</p>	
<p>4.</p>	<p>Lift top inner post and fix to wall bracket, by removing the pin, inserting top arm into bracket clevis and re-installing the pin. *** POSTS ARE TELESCOPIC***</p>	
<p>5.</p>	<p>Feed chain under & over strut (hat section) & hook back onto chain bracket. Repeat for all post to strut connections.</p>	

TO REMOVE - Reverse the steps noted above.